



AUTOMATED MERCHANDISING SYSTEMS INC.

255 West Burr Blvd., Kearneysville, WV 25430
304.725.6921 (phone) 304.725.6983 (fax)

IMPORTANT SETUP INSTRUCTIONS

USA Technologies Card Reader Antenna

The antenna used with the Credit Card Reader has been shipped as shown in Figure 1 below.



Figure 1



Figure 2

Before you operate the machine, remove the tape and reposition the antenna as shown below in Figure 2. The magnetic base will hold it in place.

(Over)

If necessary for better reception, detach the antenna connection at the rear of the Card Reader as shown in Figure 3, and move it to the top of the machine above the Card Reader as shown in Figure 4. Leave the antenna cord uncoiled and reconnect it to the Card Reader.

IMPORTANT!

NEVER LEAVE IN THE ANTENNA INSIDE THE MACHINE NEAR THE CONTROL BOARD




Figure 3



Figure 4